


BSV 8


148R9506

## Installation












Fig. 4

#### ENGLISH

### Installation

#### Refrigerants

Applicable to all common non-flammable refrigerants, including R717 and non-corrosive gases/liquids dependent on sealing material compatability. Flammable hydrocarbons are not recommended. The valve is only recommended for use in closed circuits. For further information please contact Danfoss.

### **Temperature range**

BSV 8: -30/+100°C (-22/+212°F)

### **Pressure range**

The valve is designed for a max. working pressure of 25 bar g (362 psi g). Danfoss Industrial Refrigeration A/S is supplying safety valves adjusted for a certain pressure (indicated on the ID-plate) and sealed.

Danfoss Industrial Refrigeration guarantees correct pressure as long as the seal remains unbroken.

#### Installation

The valve should be installed with the spring housing upwards (fig. 1). By mounting of the safety valve it is important to avoid the influence of thermic and dynamic stress (vibrations) (fig. 2). The valve is designed to withstand a high internal pressure. However, the piping system should be designed to avoid liquid traps and reduce the risk of hydraulic pressure caused by thermal expansion. It must be ensured that the valve is protected from pressure transients like "liquid hammer" in the system.

# Welding

If welding fittings are applied, these should be dismounted during the welding process (fig. 3). Only materials and welding methods, compatible with the flange material, must be welded to the flange. Avoid welding debris and dirt in the threads of the housing and pipes.

### **Assembly**

Remove welding slag and dirt from tubes and housing before the valve is mounted. Mount the valve as shown in fig. 4.

### **Colours and identification**

The valves are Zinc-Chromated in the factory. If further corrosion protection is required, it can be painted. Precise identification of the valve is made via the ID label on the valve housing. In cases of doubt, please contact Danfoss. Danfoss accepts no responsibility for errors and omissions. Danfoss Industrial Refrigeration reserves the right to make changes to products and specifications without prior notice.

# **DECLARATION OF CONFORMITY**

The Pressure Equipment Directive 97/23/EC



Name and Address of Manufacturer within the European Community

Danfoss Industrial Refrigeration A/S Stormosevej 10 PO Box 60 DK-8361 Hasselager Denmark

## **Description of Pressure Equipment**

Refrigerant safety valve

Type BSV 8

Nominal bore	<b>8 mm</b> (0,315 in.) for BSV 8	
Classified for	<b>Fluid Group I</b> (all refrigerants (toxic, nontoxic, flammable and nonflammable)). For further details / restrictions - see Installation Instruction.	
Temperature range	BSV 8	-30°C/+100°C (-22°F/+212°F)
Maximum allowable working pressure	BSV 8	<b>10-25 bar</b> (143-362 psi g) –30°C/+100°C (–22°F/+212°F)

## **Conformity and Assessment Procedure Followed**

Category		IV
Module		B + D
Certificate ID		B: 07 202 0511 Z 0078/1/H-0002 D: 07 202 0511 Z 0009/1/H-0001
Nominal bore	Standard application	<b>8 mm</b> (0,315 in.) for BSV 8

Name and Address of the Notified Body which carried out the Inspection

TÜV-Nord e.V. Grosse Bahnstrasse 31 22525 Hamburg, Germany

(0045)

Name and Address of the Notified Body monitoring the Manufacturer's Quality Assurance System

TÜV-Nord e.V. Grosse Bahnstrasse 31 22525 Hamburg, Germany

**References of Harmonised Standards used** 

EN 10222-4

References of other Technical Standards and Specifications used

prEN 12284 prEN 13136

AD-Merkblätter DIN 3158

Authorised Person for the Manufacturer within the European Community

Name: Morten Steen Hansen Title: Production Manager

Signature: Warfun Stein Mangen Date: 29/11/2001

148B9713 - rev. 0