



Fig. 1, DSV 2

Description	Code no.
	Size 32 (1 1/4 in.)
Spare part kit, for bonnet and cap (installation kit)	148F3023
Pos. 16 O-ring for seat 17 O-ring for housing/bonnet 23 Gasket for cap	
Dismounting kit	148F3030
Pos. 30 Gasket for flange SFV 15/DSV 2 31 Gasket for nipple SFV 15 32 Gasket for flange SFV 15-20-25/DSV 2 33 Gasket for flange SFV 20-25/DSV 2	
Repair kit, complete set of gaskets	148F3025
Pos. 8 Gasket for cone 16 O-ring for seat 17 O-ring for housing/bonnet 18 Lock pin 20 Slotted nut 23 Gasket for cap 29a Gaskets complete for packing gland 30 Gasket for flange SFV 15/DSV 2 31 Gasket for nipple SFV 15 32 Gasket for flange SFV 15-20-25/DSV 2 33 Gasket for flange SFV 20-25/DSV 2	
Packing gland incl. gaskets (with O-rings)	148B4032
Pos. 29 Packing gland incl. gaskets	
Cap incl. gasket	148B4076
Pos. 28 Cap incl. gasket	
Grease for packing gland (tube)	2452+143