



Fig.1, EVR 6 and 10 (NO)

Description	Qty	Code no. Normally Open (NO)	
EVR 6			
Service kit (a.c.)			
Pos. 5 Diaphragm assembly	1	032F0184	
14 O-ring	1		
15 Screw	4		
15 Screw	4		
17 Nut	4		
22 NO unit	1		
32 Spacer	1		
45 Rubber gasket Torx key	1		
EVR 6			
Seal kit			
Pos. 14 O-ring	1	032F0172	
45 Rubber gasket	1		
EVR 10			
Service kit (a.c.)			
Pos. 5 Diaphragm assembly	1	032F0186	
14 O-ring	1		
15 Screw	4		
15 Screw	4		
17 Nut	4		
22 NO unit	1		
32 Spacer	1		
45 Rubber gasket Torx key	1		
EVR 10			
Seal kit			
Pos. 14 O-ring	1	032F0173	
45 Rubber gasket	1		