

Danfoss  
A32F368.12.61




Fig.1, EVR 6 and 10 (NC)

Description	Qty	Code no. Normally Closed (NC)
<b>EVR 6</b>		
<b>Service kit (a.c.)</b>		
Pos. 5 Diaphragm assembly	1	<b>032F0183</b>
14 O-ring	1	
15 Screw	4	
16 Armature assembly	1	
45 Rubber gasket	1	
Torx key	1	
<b>EVR 6</b>		
<b>Seal kit</b>		
Pos. 14 O-ring	1	<b>032F0172</b>
45 Rubber gasket	1	
<b>EVR 10</b>		
<b>Service kit (a.c.)</b>		
Pos. 5 Diaphragm assembly	1	<b>032F0185</b>
14 O-ring	1	
15 Screw	4	
16 Armature assembly	1	
45 Rubber gasket	1	
Torx key	1	
<b>EVR 10</b>		
<b>Seal kit</b>		
Pos. 14 O-ring	1	<b>032F0173</b>
45 Rubber gasket	1	